Operating Instructions & Guarantee Card

HAIR STRAIGHTENER
HS4401, HS4404, HS4408, HS3406,
HS4104P, HS4101V & HS4106B

2 YEAR GUARANTEE

HOME SERVICE

MADE IN INDIA

HAVELLS

Thank you for purchasing Havells Hair Straightener. In order to make you more comfortable while using the product, please read this user manual carefully and keep it for future reference.

OPERATING INSTRUCTIONS

Parts of the straightener

A. 360° swivel power cord
B. On/Off switch.
C. LED power indicator
D. Ceramic coated heating plates.
E. Plates lock button
F. Handle cover



WARNING

1. This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of knowledge, unless they have been given supervision or instruction concerning use of the product by the person responsible for their safety.
2. Do not use this appliance near bathtubs, showers, basins or other vessels containing water. Do not use the hair straightener with wet hands or store it near a tub, sink or other place where it will be exposed to water and other liquids or high humidity.

3. Do not use steel wool, abrasive cleaning agents or aggressive liquids (such as alcohol, petrol or acetone) to clean the product. Always clean the product with a damp cloth and non-corrosive liquid cleaners.
4. Do not use the product near wound, inflammatory or allergic areas.
5. Do not make any alteration to the product or give it to any

unauthorized person for maintenance.

6. Keep the appliance away from hot gas burner, electric hot plate or similar appliance.
7. Never drop or insert any object into any of the product's openings.
8. Do not use an extension cord or a voltage converter with this product.
9. Make sure the power plug is dry before using.
10. Do not leave the unit unattended when it is plugged in or switched on.
11. Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
12. Do not use the product if it has been dropped in water or if it has been dropped and damaged or if it has a damaged cord or plug.
13. Do not use the product if handle cover removed from its position.
14. To prevent damage to the cord, do not wrap it around the unit and ensure it is stored without twisting or folding it.
15. The heating plates have coating. This coating might slowly wear away over time. However, this does not affect the performance of the appliance.
16. Do not expose the product to fire and high temperature to avoid malfunction, fire, or fire hazard caused by heat.
17. The hair straightener is designed to work on ordinary household current only, 100 V - 240 V AC, 50 Hz-60 Hz. It is not intended for commercial use.
18. Never cover the barrel with any other object.
19. For additional protection, we advise you to install a leakage current protection device (RCCB/ELCB) in the electrical circuit that supplies the bathroom. This RCCB/ELCB must have a rated residual operating current not higher than 30 mA.

HOW TO USE



1. If locked, slide the plates lock button (E) to unlock position to start using the straightener.
2. Plug the power plug in the socket. Slide the ON/OFF (B) switch button from OFF onto ON to heat up the straightener. The LED (C) light glows.

3. After approx, one minute, the straightener is ready to use.

4. Make sure your hair is completely dry and untangled before you start straightening.

5. Split your hair into small sections.

6. Place the section of hair between the plates (D) and press the straightener to make your hair stay intact.

7. Place the straightener close to the roots of section without burning the scalp.

8. Now, start moving the straightener along with your hair, in upward to downward direction.

9. Run the straightener over the sections until it is completely straight.

10. Carry the same procedure on rest of the sections in the same way.

11. After finish using, when the heating plates (D) cool down, slide the plates lock button (E) to lock position.

CLEANING AND MAINTENANCE

1. Always disconnect the hair straightener power plug from the wall socket and allow it to cool down completely before any cleaning operation.
2. Do not use abrasive cleaning agents or scrub pads. Do not use alcohol or solvents.
3. Wipe the main body and the ceramic plates with a slightly damp cloth and dry with a soft cloth.
4. Never immerse the appliance in water or any other liquid.

CAUTIONS

1. Don't touch the straightening plates when it is on or hot.
2. The straightening plates can cause burns. Avoid direct contact with the skin and eyes. Never pack the straightener when hot.
3. Do not use the straightener in case the power cord is damaged else it may cause electric shock.
4. Protect the straightener from moisture. Never put it into the dishwasher.
5. The improper use of the hair straightener may cause damage to your hairs.
6. High temperature can be reached in just a few seconds but dropping down of temperature may take longer time.
7. Never wrap the cord around the straightener.
8. The cord should not come into direct contact with hot parts and should never run in between the straightening plates.
9. Insert main cable plug to power supply ONLY when the straightener is switched off.

E-WASTE DISPOSAL

Environmental Compliances:

As per the rules laid down by the Government for environmental concern & safety, your product has been made to comply and conform to the respective regulation as listed below. This product falls under the E-WASTE (MANAGEMENT) RULES, 2022 with all amendments of Ministry of Environment, Forest & Climate Change.

RoHS Declaration: RoHS COMPLIANT

This Product is in conformity with requirements of Rule 16 of the E-WASTE (MANAGEMENT) RULES, 2022 with all amendments. The content of hazardous substances with the exemption of the applications listed in SCHEDULE II of the E-Waste (Management) Rules, 2022 with all amendments is as follows:

- Lead (Pb): not over 0.1% by weight;
- Mercury (Hg): not over 0.1% by weight;
- Cadmium (Cd): not over 0.01% by weight;
- Hexavalent Chromium (Cr6+): not over 0.1% by weight;
- Polybrominated Biphenyls (PBBs): not over 0.1% by weight;
- Polybrominated Diphenyl Ethers (PBDEs): not over 0.1% by weight.

Do's and Don'ts for disposal of product:

1. Dos:

- Always drop your used electrical/electronic products, defective spares or any accessories and packaging materials after the end of their life at the nearest authorised collection point/center.
- Make sure that your electronic products are recycled only by authorised recyclers/dismantlers.
- Segregate the packaging materials according to their respective waste disposal options and sorting for recycling.
- Protect the glass surface of any electronic product to avoid breakage.

2. Donts:

- Never dismantle your electronic product yourself.
- Never sell or give E-Waste to informal and unorganised sectors like local scrap dealer/rag pickers.
- Never dump E-Waste in garbage bins or municipal solid waste stream.
- Do not dispose your product as unsorted municipal waste.

For more information on safe disposal, recycling and collection point, visit our website https://www.mylloyd.com/about-us/social-initiatives and https://www.havells.com/en/discover-havells/ewaste-awareness.html or write a mail to ewaste@havells.com

Guarantee*

Havells Personal Grooming products are guaranteed against manufacturing defect for a period of Two Years from the date of purchase. The defective product will be repaired/replaced within guarantee period free of cost provided it is sent (freight paid), securely packed to our nearest authorized dealer/service center along with the purchase bill and guarantee card duly filled in and stamped by the selling dealer. Damaged/broken or worn-out parts will be charged basis company's list price.

The guarantee is valid subject to the following:

1. The product is used and maintained properly and the damage is not due to negligence, mishandling, toppling or falling off of the product, distorted/damaged blades, accident and attempted repairs by unauthorized persons.
2. The product is purchased from Havells authorized dealers/retailers only.
3. The serial number of the product is not missing, deleted, defaced or altered.
4. The product is used for personal/ domestic purpose only.

The guarantee shall not apply:

Havells India Ltd. shall, however, be liable up to the maximum of the price charged for the product and shall have no responsibility for any indirect or consequential damage.

Havells India Ltd.
QRG Towers, 2D, Sector -126, Expressway, Noida - 201 304 (UP), Ph. +91-120-3331000

Customer Care No.: 08045 77 1313
E-mail: customercare@havells.com, Website: www.havells.com
Join us on Facebook at www.facebook.com/havells and share your ways to save the planet!

- Copyright Subsists. Imitation of trade dress, graphics and color scheme of this document is a punishable offence.
- Diagrams/figures in this document are for illustrative purposes only.
- Due to continuous product improvement, the product illustrated on this document may vary slightly from the actual product.

GUARANTEE CARD

Customer Name _____

Customer Address _____

_____

Pin Code _____

Date of Purchase _____

Dealer's Name & Address

Dealer's Stamp:

Product Model
Hair Straightener
HS4401, HS4404, HS4408, HS3406, HS4104P, HS4101V & HS4106B

CARE360
ASSURANCE • REACH • EFFICIENCY

QR CODE

HAVELLS